

Top view of the Volvo C303 hold at roof start level

scale 1:10 cm

For your own engineering you only need to print the second page. Additional hints see here:

The dimensions of the free space are taken at the inner side from every frame member around the walls. The frames on each wall are not included. The sheet metal is 3 – 4 cm more outward, but that space is not easy to use.

This level 110 cm above the rear floor marks the height, where the sidewalls are mounted to the lower edge of the roof. That is 16 cm below the inner lining of the roof.

Consider inaccurate measurement of about half a cm...

Attention: Page is DIN-A4. Don't scale while printing.

Sectional view of the Volvo C303 hold (roof start, 110 cm above back floor) (scale 1:10 cm)

